

Rene Herse Rear Cable Hanger

- Version 2020_07_21



- The hanger is held by the seatpost binder bolt. Make sure your slot is at least 2.5 mm wide, so the bolt does not bottom out on the cable hanger.
- Strip the plastic covering from the end of the cable housing, so the housing fits smoothly into the cable hanger.

RenéHERSE